

Lifetime Warranty / Proudly MADE IN USA





Installation Instructions

1. This retro fit kit is designed for VWs with a 12 volt negative ground battery and will not work with 6 volt systems
2. **Disconnect Battery.** Do not skip this step. Also, do not try to “test” the LED array by connecting the leads directly to a battery charger. Permanent damage could occur to the LED array if you fail to heed these steps.
3. Remove the taillight housing from the car.
4. Gently remove the retaining wire holding the bulb holder to the taillight housing and save for later. Cut the two wire leads going to the bulb.
5. Install the included foam gasket to the rim of the LED taillight lens.



6. Install the LED taillight into the taillight housing and re-install the retaining wire.

QUICK & EASY!

- ① Strip wire 1/2" 
- ② Twist 
- ③ Insert 
- ④ Hand tighten 



7. Using the included blue quick connectors, connect the wire leads from the LED unit to your car according to the chart below.

Green – Ground

Red – Stop

Black – Tail

8. Connect the green wire from the LED taillight to a good body ground.
 9. Reinstall the taillight housing onto the car.
 10. Repeat for the other side
 11. Reconnect the battery.
 12. Test all taillight functions.
- Enjoy!

Technostalgia

2260 Long Dairy Rd
Graham NC 27253

e-mail: info@cool-leds.com

WWW.Cool-leds.com